

Active sensor (4...20 mA) for measuring the averaging temperature in duct applications. IP65 / NEMA 4X rated enclosure. Supplied with one continuous sensing element across the whole length of the probe to ensure

optimum accuracy and eliminate air

Technical data sheet

22MT-54.





Type Overview

Technical Data

stratification problems.

	Туре	Output signal active temperature		Probe length	
	22MT-544	420 mA		3 m	
	22MT-545	420 mA		6 m	
Electrical Data	Nominal voltage	DC 24 V			
	Nominal voltage range	DC 1535 V			
	Power consumption DC	0.5 W			
	Electrical connection	Pluggable spri 2.5 mm²	ng loaded	terminal block	max.
	Cable entry	Cable gland wi NPT conduit ac			n (1/2"
Functional Data	Sensor Technology	based on Pt10	00 1/3 DIN		
	Application	air			
	Multirange	8 measuring ra	anges selec	table	
	Current output	1x 420 mA, n	nax. load 5	00 Ω	
Measuring Data	Measured values	Temperature			
	Measuring range temperatur	Active sensor: Attention: max restricted by m data) Setting ra S0 S1 S1 S2 S3 S4 S5 S6 S7 ±0.9°F @ 70°F ±0.11°F p.a. @	. measurin hax. fluid te -5050 10120 0250 -1535 0100 -2080 0160 [±0.5°C @ 2 70°F [±0.00	g temperature emperature (se range [°F] -30130 0250 40140 30480 0100 40240 4090 0150 21°C]	Factor setting
	Time constant τ (63%) in air c	[±32.1°F p.a.@ luct Typical 100 s @		-	
		iuci Typicai 100 S @	0111/5		
Materials	Cable gland	PA6, black			
	Housing	base: PC, oran	cover: PC, orange base: PC, orange seal: NBR70, black UV resistant		



Safety Data	Ambient humidity	max. 95% RH, non-condensing	
	Ambient temperature	-30120°F [-3550°C]	
	Fluid temperature	-30120°F [-3550°C]	
	Housing surface temperature	max. 160°F [70°C]	
	Protection class IEC/EN	III, Protective Extra-Low Voltage (PELV)	
	Power source UL	Class 2 Supply	
	EU Conformity	CE Marking	
	Certification IEC/EN	IEC/EN 60730-1	
	Certification UL	cULus acc. to UL60730-1A/-2-9, CAN/CSA	
		E60730-1/-2-9	
	Degree of protection IEC/EN	IP65	
	Degree of protection NEMA/UL	NEMA 4X	
	Enclosure	UL Enclosure Type 4X	
	Quality Standard	ISO 9001	
	Mode of operation	Туре 1	
	Control pollution degree	3	
	Rated impulse voltage supply	0.8 kV	
	Construction	Independently mounted control	

Safety Notes



This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorized modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Only authorized specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.

The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

Remarks	
General Remarks Concerning Sensors	Due to self-heating with 2 wire passive sensors, the supply wire current affects the measurement accuracy. So the supply current should not be higher than the measuring current values specified in this data sheet.
Build-up of Self-Heating by Electrical Dissipative Power	Temperature sensors with electronic components always have a dissipative power which affects the temperature measurement of the ambient air. The dissipation in active temperature sensors shows a linear increase with rising operating voltage. The dissipative power should be taken into account when measuring temperature. In case of a fixed operating voltage (± 0.2 V) this is normally done by adding or reducing a constant offset value. As Belimo transducers work with a variable operating voltage, only one operating voltage can be taken into consideration, for reasons of production engineering. Transducers 010 V / 420 mA have a standard setting at an operating voltage of DC 24 V. That means, that at this voltage, the expected measuring error of the output signal will be the least. For other operating voltages, the offset error will be increased by a changing power loss of the sensor electronics.
	If a readjustment directly at the active sensor should be necessary during later operation, this

If a readjustment directly at the active sensor should be necessary during later operation, this can be done with the following adjustment methods.


- For sensors with NFC or dongle by the corresponding Belimo app
- For sensors with a trimming potentiometer on the sensor board
- For bus sensors via bus interface with a corresponding software variable



Scope of delivery

Scope of delivery	Description	Туре
	Mounting kit, with 6 mounting brackets	A-22D-A08
	Mounting plate S housing	A-22D-A09
	1/2" NPT conduit adapter	


Wiring Diagram



The adjustment of the measuring ranges is made by changing the bonding jumpers. The output value in the new measuring range is available after 2 seconds.

Setting	range [°C]	range [°F]	Factory setting
SO	-5050	-30130	
S1	-10120	0250	
S2	050	40140	
S3	0250	30480	
S4	-1535	0100	
S5	0100	40240	
S6	-2080	4090	\checkmark
S7	0160	0150	

Dimensions





Technical data sheet		22MT-54	
Туре	Probe length	Weight	
22MT-544	3 m	0.49 lb [0.22 kg]	
22MT-545	6 m	0.62 lb [0.28 kg]	